




"Wide Profile" Screen Installation - Sliding Patio



Screen




Adapter




Track




Latch



#4 x 1/2"
pan head screw




#10 x 1/2"
pan head screw



#6 x 5/8"
pan head screw


1

Remove existing screen track by rotating the back edge down as you pry it out.




2

Insert wheels of top hung adapter into top hung track as shown.




3

Position track up into screen channel. Drill 1/16" pilot holes or punch with an awl, thru holes in track into head jamb approximately 1/4" deep.




4

Fasten track to head jamb with #4 x 1/2" flat head screws.




5

Insert screen into adapter channel and rotate down engaging wheels in bottom of screen with track on sill.




6

Align adapter with edge of screen.




7

Drill 1/8" holes thru hole locations in adapter into screen from exterior of unit. Fasten with #10 x 1/2" screws.



8


Close screen door and locate position of latch on side jamb. Mark hole locations for latch. Drill 1/16" pilot holes. Fasten with (2) #6 x 5/8" pan head screws.



9

Quad Systems Only

Position screen astragal on passive screen so it does not interfere with head and sill tracks. Pre-drill (4) equally spaced 1/8" pilot holes. Fasten astragal to screen with (4) #8 x 1" pan head screws.



#8 x 1" pan head screw

